

USER MANUAL

# PRESA V2

01 **2013 Mechanism**

02 **KT Mechanism**

03 **MC Mechanism**

04 **CT100 Mechanism**

**USER MANUAL**

# **PRESA V2**

**2013 MECHANISM**

**01 Seat Height Adjustment**

**02 Tilt Tension**

**03 Tilt Limiter**

**04 Seat Depth Adjustment**

**05 Armrest Adjustment**

**06 Lumbar Height Adjustment**

# 01

## Seat Height Adjustment

Lever under right side of seat


### **To raise / lower:**

Take your weight off the seat, lift lever up.

### **To lower:**

Lift lever up and use your weight while seated.

***Allows you to adjust the height of the seat, for good support and blood circulation in the legs.***



# 02

## Tilt Tension

Knob below front side of seat

### **To increase:**

Turn knob clockwise.

### **To decrease:**

Turn knob counterclockwise.

***Set the resistance when leaning back to support and balance your weight in any position.***



# 03

## Tilt Limiter

Lever under right side of seat


### **To engage:**

Push the lever in to lock the tilting mechanism.

### **To release:**

Pull out the lever to unlock the tilting mechanism.

***Allows you to sit in an upright locked position.***



# 04

## Seat Depth Adjustment


Lever under left side of seat

### ***To move forward / backward:***

Press lever and adjust seat either forward or backward.

Release lever to lock in position.

***Allows you to adjust the position of the seat, for good support and blood circulation in the legs.***



## 05


**Armrest Adjustment**

Lever under armrest pad

**To raise or lower:**

Press lever to unlock arm,  
adjust arm, release lever to lock.

**Adjust chair's arm height to support your arms and take weight off your shoulders.**

**Saya Soul Armrest**

- Armrest up-or-down, forward-backward, sideways adjustment and angle adjustment

**Preso Soul Armrest**

- Armrest up-or-down adjustment

**Saya Armrest**

- Armrest up-or-down adjustment


# 06

## Lumbar Height Adjustment

### **To raise or lower:**

Hold lumbar support lever using finger and move up and down to adjust height.

***Allows you to adjust the position of the lumbar support, for good support and blood circulation of the back.***



**USER MANUAL**

# **PRESA V2**

**KT MECHANISM**

**01 Seat Height Adjustment**

**02 Tilt Tension**

**03 Tilt Limiter**

**04 Seat Depth Adjustment**

**05 Armrest Adjustment**

**06 Lumbar Height Adjustment**

# 01

## Seat Height Adjustment

Lever under right side of seat


### To raise / lower:

Take your weight off the seat, lift lever up.

### To lower:

Lift lever up and use your weight while seated.

***Allows you to adjust the height of the seat, for good support and blood circulation in the legs.***



# 02

## Tilt Tension

Knob below front side of seat

### **To increase:**

Turn knob clockwise.

### **To decrease:**

Turn knob counterclockwise.

***Set the resistance when leaning back to support and balance your weight in any position.***



# 03

## Tilt Limiter

Lever under left side of seat


### **To engage:**

*Recline and twist lever counterclockwise to lock the tilting mechanism.*

### **To disengage:**

*Twist lever clockwise and lean backward slightly to unlock the tilting mechanism.*

**Allows you to sit in an upright position or partially reclined locked position.**



# 04

## Seat Depth Adjustment


Lever under left side of seat

### ***To move forward / backward:***

Press lever and adjust seat either forward or backward.

Release lever to lock in position.

***Allows you to adjust the position of the seat, for good support and blood circulation in the legs.***



# 05


## Armrest Adjustment

Lever under armrest pad

### **To raise or lower:**


Press lever to unlock arm, adjust arm, release lever to lock.

**Adjust chair's arm height to support your arms and take weight off your shoulders.**



**Saya Soul Armrest**

- Armrest up-or-down, forward-backward, sideways adjustment and angle adjustment



**Preso Soul Armrest**

- Armrest up-or-down adjustment



**Saya Armrest**

- Armrest up-or-down adjustment


# 06

## Lumbar Height Adjustment

### ***To raise or lower:***

Hold lumbar support lever using finger and move up and down to adjust height.

***Allows you to adjust the position of the lumbar support, for good support and blood circulation of the back.***



**USER MANUAL**

# **PRESA V2**

**MC MECHANISM**

**01 Seat Height Adjustment**

**02 Tilt Tension**

**03 Tilt Limiter**

**04 Seat Depth Adjustment**

**05 Armrest Adjustment**

**06 Lumbar Height Adjustment**

# 01

## Seat Height Adjustment

Lever under right side of seat

### **To raise**

Take your weight off the seat, lift lever up.

### **To lower:**

Put your weight on seat and pull lever up.

***Allows you to adjust the height of the seat, for good support and blood circulation in the legs.***



# 02

## Tilt Tension

Knob located right side under seat

### **To increase:**

Turn knob clockwise.

### **To decrease:**

Turn knob counterclockwise.

***Set the resistance when leaning back to support and balance your weight in any position.***



# 03

## Tilt Limiter

Lever located left side under seat

### **To increase limit:**

Turn knob clockwise.

### **To decrease limit:**

Turn knob counterclockwise

***Allows you to sit in an upright position or partially reclined locked position.***



# 04

## Seat Depth Adjustment


Lever under left side of seat

### **To move forward / backward:**

Press lever and adjust seat either forward or backward.

Release lever to lock in position.

***Allows you to adjust the position of the seat, for good support and blood circulation in the legs.***



## 05


**Armrest Adjustment**

Lever under armrest pad

**To raise or lower:**


Press lever to unlock arm,  
adjust arm, release lever to lock.

**Adjust chair's arm height to support your arms and take weight off your shoulders.**



**Saya Soul Armrest**

- Armrest up-or-down, forward-backward, sideways adjustment and angle adjustment



**Presa Soul Armrest**

- Armrest up-or-down adjustment



**Saya Armrest**

- Armrest up-or-down adjustment


# 06

## Lumbar Height Adjustment

### **To raise or lower:**

Hold lumbar support lever using finger and move up and down to adjust height.

***Allows you to adjust the position of the lumbar support, for good support and blood circulation of the back.***



**USER MANUAL**

# **PRESA V2**

**CT100 MECHANISM**

**01 Seat Height Adjustment**

**02 Tilt Tension**

**03 Tilt Limiter**

**04 Armrest Adjustment**

**05 Lumbar Height Adjustment**

# 01

## Seat Height Adjustment

Lever under right side of seat


### **To raise**

Take your weight off the seat, turn lever clockwise.

### **To lower:**

Put your weight on seat and turn lever clockwise.

***Allows you to adjust the height of the seat, for good support and blood circulation in the legs.***



# 02

## Tilt Tension

Knob under front side of seat


### **To increase:**

Turn knob clockwise.

### **To decrease:**

Turn knob counterclockwise.

***Set the resistance when leaning back to support and balance your weight in any position.***



# 03

## Tilt Limiter

Same lever with height adjustment lever


### **To engage:**

Put your back in upright position and push lever in.

### **To release:**

Put your back in upright position and pull lever out.

***Allows you to sit in an upright locked position.***



# 04


## Armrest Adjustment

Lever under armrest pad

### **To raise or lower:**


Press lever to unlock arm, adjust arm, release lever to lock.

***Adjust chair's arm height to support your arms and take weight off your shoulders.***



**Presa Soul Armrest**

- Armrest up-or-down adjustment



**Saya Armrest**

- Armrest up-or-down adjustment


# 05

## Lumbar Height Adjustment

### **To raise or lower:**

Hold lumbar support lever using finger and move up and down to adjust height.

***Allows you to adjust the position of the lumbar support, for good support and blood circulation of the back.***



# Warranty

## Products

## Applicable Warranty Period

---

Chairs, for seating mechanism, adjustable arms, framework, and seating foam.

**5 Years**

---

Chairs gas lift, seating glides and castors.

**3 Years**

---

Third-party materials such as Fabric and Leather upholstery

**Not Applicable**

Warranty Coverage:

During first (1st ) year of purchase :

Complete warranty, free inspection and labor service.

During applicable warranty period: Limited warranty, inclusive of part cost.

After applicable warranty period: Bristol continues to provide service support.

Parts and labor shall be sole responsibility of buyer.

# Warranty

This warranty does not apply to “normal wear and tear,” and it does not apply to any product that has been damaged by transportation or that has been altered without Bristol’s express written authorization or to consumable products. A product will not be considered defective, and Bristol will not be obligated to repair or replace it, if the product is not installed and used as recommended by Bristol. This warranty does not apply to any “Customer’s Own Material” (ie, material specified by the buyer that is not a standard Bristol product offering) used in the manufacture of a Bristol product. A natural variation occurring in wood, fabric or leather is not considered a defect under the terms of this warranty. Bristol does not warrant the colorfastness or the matching of color, grain or texture of wood, fabric or leather. Bristol may discontinue some fabrics or finishes before expiration of the applicable warranty period.

# Dos & Don'ts

## Do ✓

- For sitting.
- To be placed on even surface.
- Inspect the product before first use and once every 6 months.
- Children under 6 should use the chair only under supervision.
- Always adjust chair before sitting
- Sit in correct position on chair
- Ensure chair is on proper surface

## Don't ✗

- Do not stand, jump or play on the chair.
- Do not clean with unrecommended cleaners.
- Do not use as trolley to cart objects.
- Do not sit on armrests.
- Do not place sharp objects on the chair.
- Stop using the product if there is a malfunction.
- Do not modify without supervision by qualified technicians.
- Keep away from flame.
- Do not place chairs in open air areas with direct sunlight, moist or dusty area.
- Do not place chairs with castors on slippery hard surface (eg. cement, tile) to avoid slipping.

# Contact

## Malaysia

Tel No: +603 8962 3233

Email: [export@bristol.com.my](mailto:export@bristol.com.my) (International only)  
[sales@bristol.com.my](mailto:sales@bristol.com.my) (Malaysia only)

## Singapore

Tel No: +65 6438 2178

Email: [sales@bristol.com.sg](mailto:sales@bristol.com.sg)

## India

Tel No: +91 96 8619 1391

Email: [sales@bristolindia.com](mailto:sales@bristolindia.com)

## Thailand

Tel No: +662 689 6380

Email: [sales@bristol.co.th](mailto:sales@bristol.co.th)

## Indonesia

Tel No: +62 21 2952 4141

Email: [indonesia@bristol.com.my](mailto:indonesia@bristol.com.my)

## Vietnam

Tel No: +84 79 641 9876

Email: [vietnam@bristol.com.my](mailto:vietnam@bristol.com.my)



014

Rgn No : Q112788C



014

Rgn No : E112788